
Easy Implant Removal EFR KIT


- · Bone loss-less fixture removal
- · Quick & Simple removal by two(2) Stage
- · Above 80% removal success



1. Seclect remover screw (Refer to the remover screw selecting guide)

2. Clockwise tightening by torque wrench through the screw driver (mini 80Ncm, regular 100Ncm)





5. Anti-clockwise screwing by torque wrench through the removal body (Maxium 400Ncm engagement possible)







6. Bone loss-less fixture removal by strong adhesion property between fixture & removal body